



9223 Harford Road
Baltimore, MD 21234
Tel: 410-882-0800
Tel: 800-537-3911
Fax: 410-882-5890
www.fasara.com

3M Window Film

Fasara™ Installation Instructions

Please note that these instructions do not guarantee installation success.

Step 1 – Prepare spray bottle: Fill 3 gallon spray bottle with cold water to top. Add one cap of Johnson’s Baby Shampoo. (The baby shampoo does not activate the pressure sensitive adhesive of the film but allows the installer to slide the film into position on the glass.) If the film is not sliding on the glass during installation, add a little more shampoo. If the film slides too easily, add more water.

Step 2 – Prepare work environment: Move any furniture, blinds, etc that may hinder access to the window. Lay down drop cloths to maintain a neat work area.

Step 3 – Clean side of glass that is to receive film: Wet the glass with water and soap mixture. Use your Triumph scraper to thoroughly clean dirt and debris from the glass. Make sure to scrape around the edges.

Step 4 – Squeegee glass: Wet the glass again with water and soap mixture. Use your window squeegee to wipe glass clean. Take a Bounty paper towel and run along the gaskets to remove any debris that may be trapped.

Step 5 – Apply film: Cut the width of the film out of the box 1-2 inches wider than the glass. Cut the length of the film 2 inches longer than the glass. Generously wet the glass with water and soap mixture. Align the factory edge of the film to one of the edges of the gasket and press to the glass. If the film slides off the glass there is too much shampoo in your mixture.

Step 6 – Squeegee film: Use your beveled edge window film squeegee to remove the water trapped between the glass and the film. You must use steady and firm pressure so that no water remains trapped.

Step 7 – Trim film: Use your Olfa knife and trim the film against the gasket. More experienced installers can freehand the cut. Otherwise, run the knife against your “5-way” wallpaper tool to ensure a straight cut.

Step 8 – Dry edges: Take a paper towel and run along the edges of the film to remove any excess water.

Step 9 – Flatten edges: Wrap a paper towel around the “5 way” and flatten the edges of the film by applying pressure with the “5 way” tool.

Step 10 – Clean film: Mildly spray the film with water and soap mixture and wipe away with window squeegee. This will improve the aesthetic appearance of the finished product.



3 Gallon Spray Bottle



Triumph Scraper



Beveled Edge Squeegee



5-Way Wallpaper Tool



Olfa Knife



Window Squeegee

All necessary installation tools can be purchased from Energy Products Distribution.